


UNI-TAP

AVAILABLE MATERIALS

- High strength nylon
- Available in Bulk Pack

FEATURES/ADVANTAGES

- Light to medium loads under dead, variable or vibratory conditions, in solid or hollow masonry
- Impervious to moisture
- Quick and easy to install
- Can be used in a bottomless hole



CONCERNS


- Drill recommended hole diameter

ORDER DETAIL

Order Code	Size	Masonry	Wood / Metal	Head Diameter	Grip Range	Tension Hollow Wall	Shear Hollow Material	Tension Cement Block	Head Style	Box Qty.	Master Qty.
6460000	9/32" x 1"	1/4"	9/32"	5/8"	3/16-1/2"	130	250	150	TRUSS	100	1200
6660000	9/32" x 1-5/8"	1/4"	9/32"	5/8"	3/8-1 1/8"	130	253	158	TRUSS	100	800
6760000	9/32" x 2-1/8"	1/4"	9/32"	5/8"	7/8-1 5/8"	130	274	154	TRUSS	100	800
6860000	9/32" x 2-5/8"	1/4"	9/32"	5/8"	1 3/8-2 1/8"	130	238	163	TRUSS	100	500
6960000	9/32" x 3-1/8"	1/4"	9/32"	5/8"	1 7/8-2 5/8"	130	228	150	TRUSS	100	500

INSTALLATION


- 1 Drill hole slightly deeper than fastener length.
- 2 Clean hole of debris.
- 3 Tap "Uni-Tap" into place through material to be fastened.



ZAP-IT®

AVAILABLE MATERIALS

- Zinc Zap-It body with:
- Carbon steel nail, zinc plated
 - Stainless steel nail
 - Available in Bulk pack



FEATURES/ADVANTAGES

- Required hole diameter equals anchor diameter
- Fast, easy installation
- Stainless steel nail and zinc anchor body allow for fastening in outdoor applications

CONCERNS

- Dead loads only
- Not recommended for eccentric loading

APPROVALS/LISTINGS

- G.S.A. Spec FF-S-325C, Group V, Type 2, Class 3

ORDER DETAIL

Order Code	Stainless Steel	Anchor Diameter & Length	Hole Diameter	Embedment	Tension	Shear	Box Qty.	Master Qty.
3912000	—	3/16" x 7/8"	3/16"	5/8"	—	—	100	3000
3916000	3916SSO	1/4" x 1"	1/4"	3/4"	750	1,516	100	800
3920000	3920SSO	1/4" x 1-1/4"	1/4"	1"	1,000	1,516	100	800
3924000	—	1/4" x 1-1/2"	1/4"	1-1/4"	1,100	1,516	100	800
3928000	—	1/4" x 2"	1/4"	1-3/4"	1,400	1,516	100	500
3930000	—	1/4" x 3"	1/4"	1-3/4"	1,400	1,516	100	500

INSTALLATION

- 1 Drill hole to length of product selected.
- 2 Clean hole of debris.
- 3 Insert "Zap-It" through material, place in hole and tap nail until flush with head.

